

## JOIN CABINETS

- **A.** Using the 303-520 screws provided, fasten the cabinet to the mating bracket of the other.
- **B.** Attach center feet to mating brackets. This kit contains shorter connector bolts (300-540) to use with wood feet. Be sure to use the centered hole to align foot properly with the cabinet.