


ASSEMBLY INSTRUCTIONS

4 BAY LOW PROFILE WALL MOUNT CABINET







TIP HAZARD WARNING!

Cabinet must be affixed to wall. For use to prevent tipping in compliance with capacity of cabinet specified. Use with heavier equipment may result in instability or detachment causing tip over resulting in death or serious injury.

HARDWARE












Е



F








J




K




ı




M







Н



ID	PART #	DESCRIPTION

Α	300-485	1/4-20 x 1/2" Button Head Socket Screw
В	300-465	1/4-20 x 3/4" Head Socket Screw
С	301-730	5/16 x 2.5" Lag Bolt
D	301-745	Hollow Wall Anchors
Е	300-565	Drop In Nut
F	300-470	5/16" Flat Washer
G	400-035	Leveler Wrench
Н	303-855	Universal Wall Bracket
1	300-468	1/4" Flat Washer
J	300-518	1/4-20 x 3/8" Button Head Socket Screw
K	302-310	10-32 x 5/8" Button Head Socket Screw
L	300-835	Universal Shelf Peg
М	301-055	3/8 x 2" Alligator Wall Anchors

TOOLS INCLUDED

PART #	DESCRIPTION
P-400-030	Driver Bit 1/4" Hex Key
400-030	1/4" Hex Key
400-070	1/8" Hex Key
400-080	5/32" Hex Key

3/16" Hex Key- Short Arm

TOOLS NEEDED

Drill Driver
#2 Phillips Head Screw Driver
1/2 Drill Bit for Standard Installation
3/16" Drill Bit for Wood Stud Installation
3/8" Drill Bit for Masonry Installation
Pencil
Tape Measure
Level

WARNINGS

IMPORTANT SAFETY INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING



400-058

WARNING! Failure to comply with these instructions may result in accident involving serious personal injury. Failing to follow these instructions can result in the product being damaged or being destroyed or voiding of the warranty.



CAUTION!

- Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- · Do not use outdoors
- · For Commercial Use Only

***** SAVE THESE INSTRUCTIONS *****


Accessories and Spare Parts

Please contact Salamander Designs 860.761.9500 or www.salamanderdesigns.com

1. INSTALL MOUNTING BRACKETS




TIP HAZARD WARNING! Cabinet MUST be affixed to wall.



2. LEVEL CABINET & MARK WALL

Prior to fastening to wall, it is important to level the cabinet with the floor by verifying that feet are properly adjusted.

Check and level Length and Depth of cabinet.





Loosen jam nut with supplied wrench and tighten to the locked position.



Place cabinet in desired location and mark bracket holes. Once holes have been marked move cabinet.

NOTE:


Adjustments has been provided in the bracket to mount the cabinet 0-1" of the wall to account for baseboard trim or other obstacles.


3. INSTALL WALL FASTENERS (MOST APPLICATIONS)

Install wall fasteners to marked location on wall & fasten cabinet.


NOTE: Alternate fasteners (C & F) provided for wood studs.








B Hold ends of straps between thumb and forefinger and pull toward you until channel rests flush behind wall.
Slide plastic cap along straps with either hand with flange of cap is flush with wall.



Snap straps at wall by pushing side to side, snapping of straps level with flange of cap.




Move cabinet to wall and attach bracket. Insert bolt through Bracket and tighten until snug against wall.

3B. INSTALL WALL FASTENERS (ALTERNATE)


WOOD: Locate two framing studs using a stud finder device.

MASONRY: Place brackets in desired location.


B Use a 3/16" [5mm] drill bit and drill holes 2.5" [64mm] deep.



C Insert wall anchors (M) into hole.




Place cabinet in place and fasten with washers (F) and Lag Bolts (C).



4. INSTALL BRUSH SEAL




Use with baseboard molding, trim work or gaps in uneven wall surfaces. Brush Seal Holders should stay flush to surface so that ONLY brush is showing.




6. INSTALL SHELVES

NOTE: Shelf pegs can be re-positioned if desired.

- **A.** Place shelves on pegs.
- **B.** Install shelf stops in front or back of shelf as desired.
- **C.** Shelf placement can be adjusted if necessary to either pre-drilled. locations or any location using Drop-In Nuts (E) supplied.
- D. Install accessories (IR Repeater Kit, Power Conditioner, etc) and place components.






ADJUSTMENT TIPS

3U VERTICAL RACK (OPTION)



Remove


Loosen screws on both sides. Then tilt rack until the hook is free and lift up until the rack is free from bottom screw.



Re-Install




Slide the slotted ends of the rack over the bottom screw and hook the top screw as shown.




B Tighten with provided Hex Key.


DOORS

NOTE: It is important that cabinet is level before adjusting doors, see step 2.



Adjust the tops of the doors to be parallel to the top of the cabinet.





Dismount Hinge from Hinge Plate

With one hand holding the door open, pull back on the hinge quick-release lever (B).



LIMITED WARRANTY FOR COMMERCIAL VIDEO DISPLAY STANDS AND MOUNTS

Salamander is proud to stand behind our products with industry-leading warranties. Should you ever encounter any problem with your Salamander product, let us know. We are here to make it right. 1.860.761.9500

Full warranty including limitations and warranty claim information may be found at www.salamanderdesigns.com/customer-service/warranty

Made in USA